

## PARTS NEEDED TO COMPLETE UPGRADE

- #8 x 1-1/4" T20 Pin-in-Torx Tamper Resistant Screw
- Bushing

## ITEMS NEEDED/SUPPLIED BY INSTALLER

- T20 Male Torx Bit & Driver
- Phillips screwdriver



## INSTRUCTIONS

- Make sure both sash are closed and the window is locked.
- Replace the left hand screw as viewed from the interior on the Sterling Double Hung lock with the provided #8 x 1-1/4" T20 tamper resistant screw and bushing. See pictures below.

