

Determine if you will be attaching the magnetic latch at the top or the bottom of the panels.

The magnetic latch will be attached to the panel where the panels meet when opened. Some panels will have a magnetic latch on the interior and exterior. Interior view is shown in pictures.

- Unlock unit and slide panels open.
- Separate the magnetic latches from each other and set aside.
- Start with the interior of the folding panel attached to the side jamb and work your way to the other side.
- Measure 2" down from the top of the panel and 1-1/2" in from the edge of the panel, make a mark on the panel. See Fig 1.
- Place the first side of the magnetic latch centered over the mark. Mark where each hole needs to be and then set the magnetic latch aside.
- Use a 5/64" bit to pre-drill the holes.
- **Exterior of panels only: fill the holes with sealant**
- Attach magnetic latch to the panel using the supplied screws. See Fig 2.
- Take the other side of the magnetic latch and attach it to the magnetic latch already attached to the panel. See Fig 3.
- Slide the panels together until they meet the backside of the unattached magnetic latch. See Fig 3.
- Holding the unattached magnet tight against the panel, pull the panel and unattached magnetic latch away from the attached magnetic latch. You now have the correct placement of the second magnetic latch. See Fig 4.
- Hold the magnetic latch in place and mark where each hole needs to be and then set the magnetic latch aside. **(It may be necessary to rotate the magnetic latch on the panel so the screw holes won't interfere with the screws from the hinge.)** See Fig 5.
- Use a 5/64" bit to pre-drill the holes.
- **Exterior of panels only: fill the holes with sealant**
- Attach magnetic latch to the panel using the supplied screws.

Repeat the steps above for all remaining panel sets.

