

Profile Cylinder

90° to 360° Conversion Instructions



Recommended Tools and Accessories



90° RELEASE TOOL
(provided)




2 mm or 5/64" HEX
WRENCH
(provided)

1. Remove the set screw as shown using the hex wrench.



2. Dump out the spring and pin after removing the set screw.



3. Use the 90 degree release tool if the pin does not fall freely from the cylinder body in step 2 as shown.



4. Recycle the set screw, spring, pin, and 90 degree release tool.

